

## Single P90 Wiring Diagram (2-Conductor Lead) Master Volume Master Tone

Note: No jumpers are depicted. Make sure all metal is properly grounded.

