

BLEND-TONE WIRING DIAGRAM

Telecaster with the Fralin Pickups Blend-Tone circuit

No ground jumpers depicted. Make sure all metal is grounded

