


## Telecaster® With 4-Way Switch

No Ground Jumpers are depicted. Make sure all metal is properly grounded.



**Note:** The 4-Way Switch mod requires your Neck pickup to have it's own separate chassis ground. If your pickup has a cover, snip the ground connection to the coil, and separately ground the cover to a common ground place.

⊕ = Solder Joint