

Lindy Fralin

PICKUPS

Telecaster® - With Bright Switch Push / Pull

No Ground Jumpers are depicted. Make sure all metal is properly grounded.

