

Nashville Telecaster® Wiring Diagram

5-Way Switch
Master Volume
Master Tone

Note: No jumpers are depicted. Make sure all metal is properly grounded. If using a metal plate, no jumpers are required - the plate grounds the metal.

