

TELECASTER 4-WAY SWITCHING

Bridge / Middle (Parallel) / Middle (Series) / Neck

 $\stackrel{\frown}{\mathbb{T}}$ = Ground Connection

Note: See website notes about running a new ground jumper from the Neck Pickup Cover. Otherwise, this modification **will not work**.

