


TELECASTER SERIES PARALLEL

4-Way Switching with a Push Pull Pot

Note: See website notes regarding Telecaster Neck Pickup Modification

⊕ = Ground Connection



No Ground Jumpers are depicted in this diagram. Make sure all metal is properly grounded. See an experienced tech if problems exist.